

Economy Aluminum Retrofit Drain Installation Instructions

For Use With: All types of roofing materials


Job Preparation: Remove existing Strainer and clamping ring. Remove any other existing drain components as required to enable our Economy Aluminum Drain flange to lie flush on roof membrane. Remove any debris in the existing drain pipe that interferes with proper installation.



For technical questions please call Marathon @ 800-828-8424



3310 N Benzing Road Orchard Park, NY 14127 Ph: 800-828-8424 www.marathondrains.com



Economy Aluminum Retrofit

Drain Installation Instructions

HOW TO SHORTEN OUR ALUMINUM FASTFLOW RETROFIT DRAIN

You may need to shorten our Economy Aluminum outlet length if the existing vertical distance is too shallow to accommodate our standard 12" long outlet.



For technical questions please call

Marathon @ 800-828-8424



3310 N Benzing Road Orchard Park, NY 14127 Ph: 800-828-8424 www.marathondrains.com

MEETS ANSI/SPRI RD-1 STANDARD

#1 — Make sure there is at least 4-inches of distance in the existing pipe to accommodate our Aluminum Drain. Cut drain stem to desired length.

#2 — Once the drain has been assembled, insert it into the existing water leader and complete the

assembly following 2 - 5 installation on front page (see reverse).



The minimum length of our Economy Aluminum Retrofit Drain stem

Copyright 2014 - Marathon Roofing Products